


SERVICE MANUAL

STEREO GRAPHIC EQUALIZER
CONSOLETTE

SANSUI RG-7X

(Silver & Black Model)



•SPECIFICATIONS

Input sensitivity and Impedance (1 kHz)

SOURCE IN, TAPE PLAY	150 mV/47 kilohms
(Max. input capability; 8V, 20 Hz to 20 kHz)	
MIC.....	0.5 mV/10 kilohms
(Max. input capability; 25 mV, 100 Hz to 15 kHz)	
GUITAR.....	5 mV/100 kilohms

Output level and impedance (1 kHz)

TAPE REC	150 mV/1 kilohms
PREAMP OUT.....	150 mV/1 kilohms

Total harmonic distortion (1V, 20 Hz to 20 kHz)

SOURCE IN, TAPE PLAY	0.05%
----------------------------	-------

Frequency response (0.5V)

SOURCE IN, TAPE PLAY	20 Hz to 20 kHz, +0 dB, -0.5 dB
----------------------------	------------------------------------

Signal to noise ratio (Short-circuit, A-network)

SOURCE IN, TAPE PLAY	75 dB
----------------------------	-------

Channel separation (1 kHz)

SOURCE IN, TAPE PLAY	70 dB
----------------------------	-------

Echo time

0~3 sec. (-60 dB)

Duet time.....

25 msec and 50 msec.

Others

Power voltage

110~120/220~240V (50/60 Hz)

For U.S.A and Canada	120V (60 Hz)
----------------------------	--------------

Power consumption

20 watts

Dimensions

430 mm (16-15/16") W

87 mm (3-7/16") H

228 mm (9") D

Weight

3.3 kg (7.3 lbs.) net

3.9 kg (8.6 lbs.) packed

* Design and specifications subject to change without notice for improvements.


CAUTION

1. Use only replacement parts recommended by the manufacturer.
2. Measure insulation resistance before returning the appliance to the customer to prevent electrical shock.

Sansui

SANSUI ELECTRIC CO., LTD.


1. BLOCK DIAGRAM



2. PARTS LOCATION & PARTS LIST

2-1. F-3527 Control Amp. Circuit Board (Stock No. 00748201)

Component Side




• Since some of capacitors and resistors are omitted from parts lists in this service manual, refer to the Common Parts List for capacitors & resistors, which was issued on February 1983.

Parts List

Parts No.	Stock No.	Description
• IC		
jIC1	03607700 or 46580100	NJM4558D M5218P
jIC2	03607700 or 46580100	NJM4558D M5218P
jIC3	03607700 or 46580100	NJM4558D M5218P
jIC4	03607700 or 46580100	NJM4558D M5218P
• Transistor		
IQ1	07194801	2SC1815
IQ2	07194701	2SA1015
• Diode		
ID1	03117000	RB-152
ID2	03117600 or 46086000	1S2473T77 1S1588TP
ID3	03117700	10E-2
• Zener Diode		
IDZ1	46112100 or 46112200	05Z6.8-Y 05Z6.8-Z
IRL1	11504700 or 11504701	Relay Relay
• Transistor		
mQ1	07194801	2SC1815
mQ2	07194701	2SA1015
mQ3	03086101 or 03083901	2SD357 2SD313
mQ4	03034401 or 03032301	2SB527 2SB507
• Diode		
mD1	03117000	RB-152
mDZ1	03179400 or 46114800	RD16E-B 05Z16-Y
mDZ2	03179400 or 46114800	RD16E-B 05Z16-Y
• Transistor		
nQ1	07194801	2SC1815
nQ2	03083901	2SD313
nQ3	07194801	2SC1815
nQ4	03083901	2SD313
• Zener Diode		
nDZ1	46114200	05Z13-Y
	07249100	4P Input Terminal Board
	07249100	4P Input Terminal Board
• IC		
rIC1	03607700 or 46580100	NJM4558D M5218P
rIC2	03607700 or 46580100	NJM4558D M5218P
rIC3	46080200	MN3010
rIC4	46080300	MN3101
• Diode		
rD1	03117600	1S2473T77
rD2	03117600	1S2473T77
rVR2	10351900	100kΩ(B) S.V.R., Echo level adj

2-2. F-4249 Reverberation Indicator Control Circuit Board (Stock No. 00747901)

Component Side




Parts List

Parts No.	Stock No.	Description
•Transistor		
nQ11	46367301	2SC2458
	or 46367101	2SC2603
	or 46391901	2SC2785
nQ12	46367301	2SC2458
	or 46367101	2SC2603
	or 46391901	2SC2785
nQ13	46367301	2SC2458
	or 46367101	2SC2603
	or 46391901	2SC2785
nQ14	46367301	2SC2458
	or 46367101	2SC2603
	or 46391901	2SC2785
nQ15	46367301	2SC2458
	or 46367101	2SC2603
	or 46391901	2SC2785
nQ16	46367301	2SC2458
	or 46367101	2SC2603
	or 46391901	2SC2785
nQ17	46367301	2SC2458
	or 46367101	2SC2603
	or 46391901	2SC2785

Parts No.	Stock No.	Description
nQ18	46367301	2SC2458
	or 46367101	2SC2603
	or 46391901	2SC2785
nQ19	46543501	2SC3243
nQ20	46543501	2SC3243
•IC		
nIC1	46580100	M5218P
	or 03607700	NJM4558D
•Diode		
nD11	46086000	1S1588TP
	or 03117600	1S2473T77
nD12	46086000	1S1588TP
	or 03117600	1S2473T77
nD13	46086000	1S1588TP
	or 03117600	1S2473T77
nD14	46086000	1S1588TP
	or 03117600	1S2473T77
nD15	46086000	1S1588TP
	or 03117600	1S2473T77
nC11	08451700	1uF 50V F B

2-3. F-3531 Mic Amp. Circuit Board (Stock No. 00748601)

Component Side




Parts List

Parts No.	Stock No.	Description
•IC glC1	07208900	NJM4558D-X
oS1	46612100	Push SW., MIC/GUITAR
oJ1	46085000	Jack, MIC

2-4. F-3523 Low Range Filter Amp.
Circuit Board (Stock No. 00748001)

Component Side




Parts List

Parts No.	Stock No.	Description
•IC		
jIC5	03607700	NJM4558D
	or 46580100	M5218P
jIC6	03607700	NJM4558D
	or 46580100	M5218P
jIC7	03607700	NJM4558D
	or 46580100	M5218P
jIC8	03607700	NJM4558D
	or 46580100	M5218P
jIC9	03607700	NJM4558D
	or 46580100	M5218P

2-5. F-3525 High Range Filter Amp.
Circuit Board (Stock No. 00748101)

Component Side




Parts List

Parts No.	Stock No.	Description
•IC		
jIC10	03607700	NJM4558D
	or 46580100	M5218P
jIC11	03607700	NJM4558D
	or 46580100	M5218P
jIC12	03607700	NJM4558D
	or 46580100	M5218P
jIC13	03607700	NJM4558D
	or 46580100	M5218P
jIC14	03607700	NJM4558D
	or 46580100	M5218P

•Note: The circuit boards, F-4247, F-4248, F-3532, F-3528, F-3529 & F-3530 are not supplied as the assembled. However, the individual parts on the circuit board are provided by orders.


2-6. F-4247 Low Range Volume Circuit Board
Component Side



Parts List

Parts No.	Stock No.	Description
jVR1	46612400	250kΩ x 2 Slide V.R., 30 Hz
jVR2	46612400	250kΩ x 2 Slide V.R., 60 Hz
jVR3	46612400	250kΩ x 2 Slide V.R., 125 Hz
jVR4	46612400	250kΩ x 2 Slide V.R., 250 Hz
jVR5	46612400	250kΩ x 2 Slide V.R., 500 Hz

2-7. F-4248 High Range Volume Circuit Board
Component Side




Parts List

Parts No.	Stock No.	Description
jVR6	46612400	250kΩ x 2 Slide V.R., 1 kHz
jVR7	46612400	250kΩ x 2 Slide V.R., 2 kHz
jVR8	46612400	250kΩ x 2 Slide V.R., 4 kHz
jVR9	46612400	250kΩ x 2 Slide V.R., 8 kHz
jVR10	46612400	250kΩ x 2 Slide V.R., 16 kHz

2-8. F-3532 Mic & Reverberation Control Volume Circuit Board

Component Side




Parts List

Parts No.	Stock No.	Description
rVR1	46097700	100kΩ(B) × 4 V.R., DEPTH
gVR1L	46097600	20kΩ(A) V.R., LEVEL-CH1
gVR1R	46097600	20kΩ(A) V.R., LEVEL-CH2
gVR2L	46097500	250kΩ(MN) V.R., PANPOT-CH1
gVR2R	46097500	250kΩ(MN) V.R., PANPOT-CH2

2-9. F-3528 POWER Switch Circuit Board

Component Side




Parts List

Parts No.	Stock No.	Description
pC1	46425800	10000pF 400V C.C.
pS1	46360400	Push SW., POWER

2-10. F-3529 REVERB-LINE/-MIC/-MODE Switch Circuit Board

Component Side




Parts List

Parts No.	Stock No.	Description
oS2	46612300	Push SW.

2-11. F-3530 LINE INPUT/EQUALIZER/ EFFECT REC Circuit Board

Component Side



Parts List

Parts No.	Stock No.	Description
oS3	46612200	Push SW.

● Abbreviations

C.R.	: Carbon Resistor
S.R.	: Solid Resistor
Ce.R.	: Cement Resistor
M.R.	: Metal Film Resistor
F.R.	: Fusing Resistor
N.I.R.	: Non-Inflammable Resistor
C.C.	: Ceramic Capacitor
C.T.	: Ceramic Capacitor, Temperature Compensation
E.C.	: Electrolytic Capacitor
E.L.	: Low Leak Electrolytic Capacitor

E.B.	: Bi-Polar Electrolytic Capacitor
E.BL.	: Low Leak Bi-Polar Electrolytic Capacitor
Ta.C.	: Tantalum Capacitor
F.C.	: Film Capacitor
M.P.	: Metalized Paper Capacitor
P.C.	: Polystyrene Capacitor
G.C.	: Gimmie Capacitor
V.R.	: Variable Resistor
S.V.R.	: Semi Variable Resistor
SW.	: Switch

A

B

C

D



E

F

G


H

3. SCHEMATIC DIAGRAM




4. OTHER PARTS

4-1. Front View



4-2. Top View



Parts List <Front View>

Parts No.	Stock No.	Description
<Silver & Black Model>		
2	07601400	Bonnet
3	46612400	250kΩ x 2 Slide V.R., Equalizer level
5	46612300	Push SW., REVERB-LINE/-MIC/-MODE
8	07764300	Indicator Window
9	46612200	Push SW., LINE INPUT/EQUALIZER/EFFECT REC
10	46612100	Push SW., CH-2 MIC/GUITAR
11	46085000	Jack, MIC
13	46097600	20kΩ (A) V.R., CH-1, 2 LEVEL
15	46097500	250kΩ (MN) V.R., CH-1, 2 PANPOT
16	46097700	100kΩ (B) x 4 V.R., REVERB-DEPTH
17	46360400	Push SW., POWER
<Silver Model>		
1	47210100	Front Panel Ass'y
4	47211000	Slide Knob, Equalizer level
6	07580100	Push Knob, LINE INPUT etc.
7	47211500	Sub Panel Ass'y
12	47221100	Push Knob, EFFECT REC/REVERB-MODE
14	07764500	Knob, CH-1, 2 LEVEL/PANPOT
18	47210600	Push Knob, POWER
<Black Model>		
1	47210200	Front Panel Ass'y
4	47211100	Slide Knob, Equalizer level


Parts List <Top View>

Parts No.	Stock No.	Description
1	38004700	Power Supply Cord
2	39106000	Strain Relief
3	07189600	AC Outlet
4	07249100	4P Input Terminal, TAPE
5	07249100	4P Input Terminal, SOURCE IN/PREAMP OUT
6	07601810	Side Panel (Right)
7	46607600	Indicator Box Ass'y
7-1	46133000	Main Indicator Lamp with Socket
7-2	46132900	Sub Indicator Lamp
8	07601710	Side Panel (Left)
9	15004201	Power Transformer

5. ECHO LEVEL ADJUSTMENT (See Top View)

SETTING: 1) Connect the measurement units as Fig. 5-1.
2) Set the control knobs as follows.


REVERB-MIC	OFF	REVERB-LINE	ON
REVERB-MODE	ECHO	REVERB-DEPTH	Max.
CH1/CH2 LEVEL	Min.	CH1/CH2 PANPOT	Center
LINE INPUT	SOURCE	EQUALIZER	OFF



INPUT SIGNAL	MEASURE OUTPUT	STEP	ADJUSTMENT
800 Hz 1.5V SG	PREAMP OUT	1	Turn the semi-variable resistor rVR2 (F-3527) fully clockwise.
SOURCE IN	VTVM, Scope	2	Push LINE INPUT switch to set to TAPE position.
		3	Confirm that the reverberation circuit starts to oscillate, and its wave form comes out from PREAMP OUT.
		4	Turn rVR2 slowly counterclockwise until the oscillation stops.

6. PACKING LIST

Parts No.	Stock No.	Description
1	07599500	Vinyl Cover
2	07661900	Styrofoam Packing
3	47209900	Carton Case (Silver Model)
	47210000	Carton Case (Black Model)



7. ACCESSORY LIST

Stock No.	Description
46606600	Operating Instruction
38103300	PJP Cord

SANSUI ELECTRIC CO., LTD.: 14-1, Izumi 2-chome, Suginami-ku, Tokyo 168 Japan
PHONE: (03) 324-8891/TELEX: 232-2076 (International Division)
SANSUI ELECTRONICS CORPORATION: 1250 Valley Brook Ave, Lyndhurst, N.J. 07071 U.S.A.
333 West Alondra Blvd, Gardena, California 90247 U.S.A.
3036 Koapaka St, Honolulu, Hawaii 96819 U.S.A.
Unit 10A, Lyon Industrial Estate, Rockware Avenue, Greenford, Middx UB6, OAI, England
Paul Ehrlich Strasse 8, 6074 Rödermark 2, West Germany

Sansui